

Quick Start Guide for the Toro 621 E Snow Thrower

To quickly start your Toro 621 E snowthrower using the electric starter, follow these steps:

Quick Start Guide (Electric Start)

Before you begin:

- Ensure the engine has been filled with the correct type and amount of oil (5W-30 synthetic is recommended below 40°F/4°C).
- Fill the fuel tank with fresh gasoline (no oil mix is needed as it is a 4-cycle engine).

Starting Procedure:

1. Insert the Key: Make sure the ignition key is fully inserted into the ignition slot and turned to the ON position.
2. Move the Choke: Move the choke lever to the FULL CHOKE (start) position.
3. Prime the Engine: Push the primer bulb three times firmly with your thumb, holding it in for a second each time. (Note: If the engine is already warm from recent use, you can skip priming and potentially the choke step).
4. Connect Electric Start: Plug a grounded, three-wire extension cord into the snowthrower's electric start receptacle and then into a properly grounded electrical outlet.
5. Start the Engine: Press the electric start button to start the engine.
 1. Important: Do not run the starter for more than 5 seconds at a time. Wait 5-10 seconds between attempts to avoid overheating the starter motor. If the engine doesn't start after a few attempts, you may need to wait 40 minutes for the starter to cool down.

6. Unplug and Adjust Choke: Once the engine starts, immediately unplug the extension cord from both the outlet and the machine.
7. Move Choke to Run: After a few seconds of the engine running smoothly, move the choke lever slowly to the HALF CHOKE, and then to the OFF (RUN) position as the engine warms up fully.

To operate the snowthrower, squeeze the control bar to engage the paddles/auger.